



# POCKETRAK 2G Update Guide

This document explains how to update the POCKETRAK 2G firmware to the latest version.

## Precautions (Please be sure to read this section first!)

- The user assumes full responsibility for the update.
- You should back up all important data before updating.
- If you fail to follow these instructions properly, or turn off the POCKETRAK 2G while the update is in progress, the POCKETRAK 2G may be damaged.
- If the POCKETRAK 2G does not work properly after updating, and you've tried updating several times, please contact your Yamaha dealer.
- The screens shown in this guide are of Windows Vista. The screens, the menu items and buttons displayed on your computer may not exactly match those shown in this documentation, depending on the OS version or manufacturer of your computer.
- This documentation is copyrighted by Yamaha Corporation.
- Reproducing or modifying all or part of this documentation without permission is strictly prohibited.

## Firmware version history

### V2.01A Improved the maximum bit rate in XHQ mode for MP3 recording.

The bit rate in XHQ mode has been improved from 128kbps to 160kbps in the public area (128kbps remains the setting for the security area).


The recording time in XHQ mode has been changed from approx. 33hr.10min. to approx. 25hr.20min. in the public area.

## Updating the firmware (Total nine (9) steps)


- 1.** You should save important data in the POCKETRAK 2G to your computer as backup before updating.
- 2.** Download the latest firmware from the following website.  
<http://www.yamahasynt.com/download/>
- 3.** Turn off the power of the POCKETRAK 2G, and then connect the USB terminal on the POCKETRAK 2G to a USB connector on your computer.

- Click [Start] menu → [Computer], and then double-click the Removable Disk icon (Macintosh users: double-click the NO NAME icon) to open the window.


**Note** If the “AutoPlay” screen appears, double-click “Open folder to view files” to open the window.




- Copy the file “285BXE21.SUD” extracted from the downloaded file to the root folder of the Removable Disk that contains the ALARM, DATA, LINE, Manual, MUSIC, VOICE folders.



**Important** Do not copy the file to the root folder of the Removable Disk (Macintosh users: NO NAME) that contains DATA\_S, VOICE\_S folders. If you do so, the POCKETRAK 2G will not be updated.

- Click the  icon (Safely Remove Hardware) on the taskbar at the bottom right of the Windows screen to disconnect the POCKETRAK 2G from your computer, and then click [Safely remove USB Mass Storage Device].

7. After the computer displays the following message, click [OK], and then remove the USB terminal.



**Note** Macintosh users: Drag and drop the NO NAME icon on the desktop to the Trash to disconnect the POKETRAK 2G from your computer.

8. Turn on the power of the POKETRAK 2G, press and hold down the MENU/STOP button for at least two seconds, select COMMON→UPDATE→YES, then press the ► button.  
POKETRAK 2G starts writing the firmware.
9. The writing will be completed after about ten seconds, and then return to the normal screen.  
The update is now complete.