

# Clavinova®

---

DATA LIST

CLP-785

DATENLISTE

CLP-795GP

LISTE DES DONNÉES

LISTA DE DATOS

LISTA DE DADOS

データリスト

XG Voice List..... 2

XG Voice-Liste

Liste des sonorités XG

Lista de sonidos XG

Lista de vozes XG

XG ボイス一覧

XG Drum Kit List ..... 6

Liste der Drum Kits (Schlagzeug-Sets)

Liste des kits de percussion XG

Lista del kit de batería XG

Lista do conjunto de percussão XG

XG ドラムキット一覧

EN

DE

FR

ES

PT

JA

# XG Voice List / XG Voice-Liste / Liste des sonorités XG / Lista de sonidos XG / Lista de voces XG / XGボイス一覧

Voice group	Voice name	MSB	LSB	PRG	
PIANO	GrandPiano	0	0	1	
	GrandPiano KSP	0	1	1	
	MellowGndPiano	0	18	1	
	PianoStrings	0	40	1	
	Dream	0	41	1	
	BrightPiano	0	0	2	
	BrightPiano KSP	0	1	2	
	E.GrandPiano	0	0	3	
	E.GndPiano KSP	0	1	3	
	DetunedCP80	0	32	3	
	LayeredCP1	0	40	3	
	LayeredCP2	0	41	3	
	Honkytonk	0	0	4	
	Honkytonk KSP	0	1	4	
	ElectricPiano1	0	0	5	
	E.Piano1 KSP	0	1	5	
	Mellow E.Piano	0	18	5	
	ChorusEP1	0	32	5	
	Hard E.Piano	0	40	5	
	Vxfade E.Piano1	0	45	5	
	60s E.Piano1	0	64	5	
	ElectricPiano2	0	0	6	
	E.Piano2 KSP	0	1	6	
	ChorusEP2	0	32	6	
	DXEPHard	0	33	6	
	DXLegend	0	34	6	
	DXPhaseEP	0	40	6	
	DX+AnalogEP	0	41	6	
	DXKotoEP	0	42	6	
	VXfadeE.Piano2	0	45	6	
	Harpsichord	0	0	7	
	Harpsichord KSP	0	1	7	
	Harpsichord2	0	25	7	
	Harpsichord3	0	35	7	
	Clavi	0	0	8	
	Clavi KSP	0	1	8	
	ClaviWah	0	27	8	
	PulseClavi	0	64	8	
	PierceClavi	0	65	8	
	CHROMATIC PERC.	Celesta	0	0	9
		Glockenspiel	0	0	10
		MusicBox	0	0	11
		MusicBox2	0	64	11
		Vibraphone	0	0	12
		Vibraphone KSP	0	1	12
		HardVibes	0	45	12
		Marimba	0	0	13
		Marimba KSP	0	1	13
		SineMarimba	0	64	13
		Balimba	0	97	13
		LogDrums	0	98	13
		Xylophone	0	0	14
		TubularBells	0	0	15
		ChurchBells	0	96	15
		Carillon	0	97	15
		Dulcimer	0	0	16
		Dulcimer2	0	35	16
Cimbalom		0	96	16	
Santur		0	97	16	
ORGAN		DrawbarOrgan	0	0	17
		DetDrawOrgan	0	32	17
		60sDrawOrgan1	0	33	17
	60sDrawOrgan2	0	34	17	
	70sDrawOrgan1	0	35	17	
	DrawbarOrgan2	0	36	17	
	60sDrawOrgan3	0	37	17	
	EvenBarOrgan	0	38	17	
	16+2'2_3Organ	0	40	17	
	OrganBass	0	64	17	

Voice group	Voice name	MSB	LSB	PRG	
ORGAN	70sDrawOrgan2	0	65	17	
	CheezyOrgan	0	66	17	
	DrawbarOrgan3	0	67	17	
	Perc.Organ1	0	0	18	
	70sPerc.Organ1	0	24	18	
	DetPerc.Organ	0	32	18	
	LightOrgan	0	33	18	
	Perc.Organ2	0	37	18	
	RockOrgan	0	0	19	
	RotaryOrgan	0	64	19	
	SlowRotary	0	65	19	
	FastRotary	0	66	19	
	ChurchOrgan	0	0	20	
	ChurchOrgan3	0	32	20	
	ChurchOrgan2	0	35	20	
	NotreDame	0	40	20	
	OrganFlute	0	64	20	
	Trem.OrganFlute	0	65	20	
	ReedOrgan	0	0	21	
	PuffOrgan	0	40	21	
	Accordion	0	0	22	
	AccordionItalian	0	32	22	
	Harmonica	0	0	23	
	Harmonica2	0	32	23	
TangoAccordion	0	0	24		
TangoAccord2	0	64	24		
GUITAR	NylonGuitar	0	0	25	
	NylonGuitar2	0	16	25	
	NylonGuitar3	0	25	25	
	VelocityGt-Harmo	0	43	25	
	Ukulele	0	96	25	
	SteelGuitar	0	0	26	
	SteelGuitar2	0	16	26	
	12StrGuitar	0	35	26	
	Nylon&Steel	0	40	26	
	Steel&Body	0	41	26	
	Mandolin	0	96	26	
	JazzGuitar	0	0	27	
	MellowGuitar	0	18	27	
	JazzAmp	0	32	27	
	CleanGuitar	0	0	28	
	ChorusGuitar	0	32	28	
	MutedGuitar	0	0	29	
	FunkGuitar1	0	40	29	
	MuteSteelGuitar	0	41	29	
	FunkGuitar2	0	43	29	
	JazzMan	0	45	29	
	Overdriven	0	0	30	
	GuitarPinch	0	43	30	
	DistortionGuitar	0	0	31	
	FeedbackGuitar	0	40	31	
	FeedbackGtr2	0	41	31	
	GuitarHarmonics	0	0	32	
	GuitarFeedback	0	65	32	
	GuitarHarmonic2	0	66	32	
	BASS	AcousticBass	0	0	33
		JazzRhythm	0	40	33
		VXUprghtBass	0	45	33
FingerBass		0	0	34	
FingerBassDark		0	18	34	
FlangeBass		0	27	34	
Bass&DistEG		0	40	34	
FingerSlapBass		0	43	34	
FingerBass2		0	45	34	
ModulatedBass		0	65	34	
PickBass		0	0	35	
MutePickBass		0	28	35	
FretlessBass		0	0	36	
FretlessBass2		0	32	36	

Voice group	Voice name	MSB	LSB	PRG	
BASS	FretlessBass3	0	33	36	
	FretlessBass4	0	34	36	
	SynthFretless	0	96	36	
	SmthFretless	0	97	36	
	SlapBass1	0	0	37	
	ResonantSlap	0	27	37	
	PunchThumb	0	32	37	
	SlapBass2	0	0	38	
	VeloSwitchSlap	0	43	38	
	SynthBass1	0	0	39	
	SynthBass1Dark	0	18	39	
	FastResoBass	0	20	39	
	AcidBass	0	24	39	
	ClaviBass	0	35	39	
	TechnoBass	0	40	39	
	Orbiter	0	64	39	
	SquareBass	0	65	39	
	RubberBass	0	66	39	
	Hammer	0	96	39	
	SynthBass2	0	0	40	
	MellowSynBass	0	6	40	
	SequenceBass	0	12	40	
	ClickSynthBass	0	18	40	
	SynthBass2Dark	0	19	40	
	SmoothSynBass	0	32	40	
	ModulrSynBass	0	40	40	
	DXBass	0	41	40	
	XWireBass	0	64	40	
	STRINGS	Violin	0	0	41
		SlowAttackViolin	0	8	41
		Viola	0	0	42
		Cello	0	0	43
		Contrabass	0	0	44
		TremoloStrings	0	0	45
		SlwAtkTremStr	0	8	45
		SuspenseStrings	0	40	45
		PizzicatoStrings	0	0	46
		OrchestralHarp	0	0	47
		YangQin	0	40	47
		Timpani	0	0	48
ENSEMBLE		Strings1	0	0	49
		StereoStrings	0	3	49
	SlwAtkStrings	0	8	49	
	ArcsStrings	0	24	49	
	60sStrings	0	35	49	
	Orchestra	0	40	49	
	Orchestra2	0	41	49	
	TremoloOrchestra	0	42	49	
	VelocityStrings	0	45	49	
	Strings2	0	0	50	
	StereoSlwStrings	0	3	50	
	LegatoStrings	0	8	50	
	WarmStrings	0	40	50	
	Kingdom	0	41	50	
	70sStrings	0	64	50	
	Strings3	0	65	50	
	SynthStrings1	0	0	51	
	ResonantStrings	0	27	51	
	SynthStrings4	0	64	51	
	SynthStrings5	0	65	51	
	SynthStrings2	0	0	52	
	ChoirAahs	0	0	53	
	StereoChoir	0	3	53	
	ChoirAahs2	0	16	53	
	MellowChoir	0	32	53	
	ChoirStrings	0	40	53	
	VoiceOohs	0	0	54	
	SynthVoice	0	0	55	
	SynthVoice2	0	40	55	

Voice group	Voice name	MSB	LSB	PRG	
ENSEMBLE	Choral	0	41	55	
	AnalogVoice	0	64	55	
	OrchestraHit	0	0	56	
	OrchestraHit2	0	35	56	
	Impact	0	64	56	
	BRASS	Trumpet	0	0	57
Trumpet2		0	16	57	
BrightTrumpet		0	17	57	
WarmTrumpet		0	32	57	
Trombone		0	0	58	
Trombone2		0	18	58	
Tuba		0	0	59	
Tuba2		0	16	59	
MutedTrumpet		0	0	60	
FrenchHorn		0	0	61	
FrenchHornSolo		0	6	61	
FrenchHorn2		0	32	61	
HornOrchestra		0	37	61	
BrassSection		0	0	62	
Tp&TbSection		0	35	62	
BrassSection2		0	40	62	
HighBrass		0	41	62	
MellowBrass		0	42	62	
SynthBrass1		0	0	63	
QuackBrass		0	12	63	
ResoSynthBrass		0	20	63	
PolyBrass		0	24	63	
SynthBrass3		0	27	63	
JumpBrass		0	32	63	
An.VeloBrass1		0	45	63	
AnalogBrass1		0	64	63	
SynthBrass2		0	0	64	
SoftBrass		0	18	64	
SynthBrass4		0	40	64	
ChoirBrass		0	41	64	
An.VeloBrass2		0	45	64	
AnalogBrass2		0	64	64	
REED		SopranoSax	0	0	65
		AltoSax	0	0	66
		SaxSection	0	40	66
		HyperAltoSax	0	43	66
		TenorSax	0	0	67
		BreathyTenor	0	40	67
		SoftTenorSax	0	41	67
		TenorSax2	0	64	67
	BaritoneSax	0	0	68	
	Oboe	0	0	69	
	EnglishHorn	0	0	70	
	Bassoon	0	0	71	
	Clarinet	0	0	72	
	PIPE	Piccolo	0	0	73
Flute		0	0	74	
Recorder		0	0	75	
PanFlute		0	0	76	
BlownBottle		0	0	77	
Shakuhachi		0	0	78	
Whistle		0	0	79	
Ocarina		0	0	80	
SYNTH LEAD		SquareLead	0	0	81
		SquareLead2	0	6	81
	LMSquare	0	8	81	
	Hollow	0	18	81	
	Shroud	0	19	81	
	Mellow	0	64	81	
	SoloSine	0	65	81	
	SineLead	0	66	81	
	SawtoothLead	0	0	82	
	SawtoothLead2	0	6	82	
ThickSaw	0	8	82		

Voice group	Voice name	MSB	LSB	PRG
SYNTH LEAD	DynamicSaw	0	18	82
	DigitalSaw	0	19	82
	BigLead	0	20	82
	HeavySynth	0	24	82
	WaspySynth	0	25	82
	PulseSaw	0	40	82
	Dr.Lead	0	41	82
	VelocityLead	0	45	82
	SequenceAnalog	0	96	82
	CalliopeLead	0	0	83
	PureLead	0	65	83
	ChiffLead	0	0	84
	Rubby	0	64	84
	CharangLead	0	0	85
	DistortedLead	0	64	85
	WireLead	0	65	85
	VoiceLead	0	0	86
	SynthAahs	0	24	86
	VoxLead	0	64	86
	FifthsLead	0	0	87
BigFive	0	35	87	
Bass&Lead	0	0	88	
Big&Low	0	16	88	
Fat&Perky	0	64	88	
SoftWhirl	0	65	88	
SYNTH PAD	NewAgePad	0	0	89
	Fantasy	0	64	89
	WarmPad	0	0	90
	ThickPad	0	16	90
	SoftPad	0	17	90
	SinePad	0	18	90
	HornPad	0	64	90
	RotaryStrings	0	65	90
	PolySynthPad	0	0	91
	PolyPad80	0	64	91
	ClickPad	0	65	91
	AnalogPad	0	66	91
	SquarePad	0	67	91
	ChoirPad	0	0	92
	Heaven	0	64	92
	Itopia	0	66	92
	CCPad	0	67	92
	BowedPad	0	0	93
	Glacier	0	64	93
	GlassPad	0	65	93
	MetallicPad	0	0	94
	TinePad	0	64	94
	PanPad	0	65	94
	HaloPad	0	0	95
	SweepPad	0	0	96
	Shwimmer	0	20	96
	Converge	0	27	96
PolarPad	0	64	96	
Celestial	0	66	96	
SYNTH EFFECTS	Rain	0	0	97
	ClaviPad	0	45	97
	HarmoRain	0	64	97
	AfricanWind	0	65	97
	Carib	0	66	97
	SoundTrack	0	0	98
	Prologue	0	27	98
	Ancestral	0	64	98
	Crystal	0	0	99
	SynthDrumComp	0	12	99
	Popcorn	0	14	99
	TinyBells	0	18	99
	RoundGlocken	0	35	99
	GlockenChime	0	40	99
	ClearBells	0	41	99

Voice group	Voice name	MSB	LSB	PRG
SYNTH EFFECTS	ChorusBells	0	42	99
	SynthMallet	0	64	99
	SoftCrystal	0	65	99
	LoudGlocken	0	66	99
	ChristmasBells	0	67	99
	VibraphoneBells	0	68	99
	DigitalBells	0	69	99
	AirBells	0	70	99
	BellHarp	0	71	99
	Gamelimba	0	72	99
	Atmosphere	0	0	100
	WarmAtmos.	0	18	100
	HolwRelease	0	19	100
	NylonEl.Piano	0	40	100
	NylonHarp	0	64	100
	HarpVox	0	65	100
	AtmospherePad	0	66	100
	Planet	0	67	100
	Brightness	0	0	101
	FantasyBells	0	64	101
	Smokey	0	96	101
	Goblins	0	0	102
	GoblinsSynth	0	64	102
	Creeper	0	65	102
	RingPad	0	66	102
	Ritual	0	67	102
	ToHeaven	0	68	102
	Night	0	70	102
	Glisten	0	71	102
	BellChoir	0	96	102
Echoes	0	0	103	
Echoes2	0	8	103	
EchoPan	0	14	103	
EchoBells	0	64	103	
BigPan	0	65	103	
SynthPiano	0	66	103	
Creation	0	67	103	
Stardust	0	68	103	
Reso&Panning	0	69	103	
ScienceFiction	0	0	104	
Starz	0	64	104	
ETHNIC	Sitar	0	0	105
	DetunedSitar	0	32	105
	Sitar2	0	35	105
	Tambra	0	96	105
	Tamboura	0	97	105
	Banjo	0	0	106
	MutedBanjo	0	28	106
	Rabab	0	96	106
	Gopichant	0	97	106
	Oud	0	98	106
	Shamisen	0	0	107
	Koto	0	0	108
	Taisho-kin	0	96	108
	Kanoon	0	97	108
	Kalimba	0	0	109
Bagpipe	0	0	110	
Fiddle	0	0	111	
Shanai	0	0	112	
Shanai2	0	64	112	
Pungi	0	96	112	
Hichiriki	0	97	112	
PERCUSSIVE	TinkleBell	0	0	113
	Bonang	0	96	113
	Altair	0	97	113
	GamelanGongs	0	98	113
	StereoGamelan	0	99	113
	RamaCymbal	0	100	113
AsianBells	0	101	113	

Voice group	Voice name	MSB	LSB	PRG
PERCUSSIVE	Agogo	0	0	114
	SteelDrums	0	0	115
	GlassPercussion	0	97	115
	ThaiBells	0	98	115
	Woodblock	0	0	116
	Castanets	0	96	116
	TaikoDrum	0	0	117
	GranCassa	0	96	117
	MelodicTom	0	0	118
	MelodicTom2	0	64	118
	RealTom	0	65	118
	RockTom	0	66	118
	SynthDrum	0	0	119
	AnalogTom	0	64	119
ElectroPerc.	0	65	119	
ReverseCymbal	0	0	120	
SOUND EFFECTS	GuitarFretNoise	0	0	121
	BreathNoise	0	0	122
	Seashore	0	0	123
	BirdTweet	0	0	124
	TelephoneRing	0	0	125
	Helicopter	0	0	126
	Applause	0	0	127
	Gunshot	0	0	128
SFX	CuttingNoise	64	0	1
	CuttingNoise2	64	0	2
	StringSlap	64	0	4
	FluteKeyClick	64	0	17
	Shower	64	0	33
	Thunder	64	0	34
	Wind	64	0	35
	Stream	64	0	36
	Bubble	64	0	37
	Feed	64	0	38
	Dog	64	0	49
	Horse	64	0	50
	BirdTweet2	64	0	51
	Ghost	64	0	55
	Maou	64	0	56
	PhoneCall	64	0	65
	DoorSqueak	64	0	66
	DoorSlam	64	0	67
	ScratchCut	64	0	68
	ScratchSplit	64	0	69
	WindChime	64	0	70
	TelephoneRing2	64	0	71
	CarEngineIgn	64	0	81
	CarTiresSquel	64	0	82
	CarPassing	64	0	83
	CarCrash	64	0	84
	Siren	64	0	85
	Train	64	0	86
	JetPlane	64	0	87
	Starship	64	0	88
	Burst	64	0	89
	RollerCoaster	64	0	90
	Submarine	64	0	91
	Laugh	64	0	97
Scream	64	0	98	
Punch	64	0	99	
Heartbeat	64	0	100	
FootSteps	64	0	101	
MachineGun	64	0	113	
LaserGun	64	0	114	
Explosion	64	0	115	
Firework	64	0	116	

# XG Drum Kit List / Liste der Drum Kits (Schlagzeug-Sets) / Liste des kits de percussion XG / Lista del kit de batería XG / Lista do conjunto de percussão XG / XGドラムキット一覧

Kit Name		Standard Kit 1			Standard Kit 2			Room Kit			Rock Kit			Electro Kit		
MSB-LSB-PC# (Org: 1)		127-0-1			127-0-2			127-0-9			127-0-17			127-0-25		
Note#	MIDI Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	Surdo Mute		3	Surdo Mute		3	Surdo Mute		3	Surdo Mute		3	Surdo Mute		3
14	D-1	Surdo Open		3	Surdo Open		3	Surdo Open		3	Surdo Open		3	Surdo Open		3
15	D#-1	Hi Q			Hi Q			Hi Q			Hi Q			Hi Q		
16	E-1	Whip Slap			Whip Slap			Whip Slap			Whip Slap			Whip Slap		
17	F-1	Scratch H		4	Scratch H		4	Scratch H		4	Scratch H		4	Scratch H		4
18	F#-1	Scratch L		4	Scratch L		4	Scratch L		4	Scratch L		4	Scratch L		4
19	G-1	Finger Snap			Finger Snap			Finger Snap			Finger Snap			Finger Snap		
20	G#-1	Click Noise			Click Noise			Click Noise			Click Noise			Click Noise		
21	A-1	Metronome Click			Metronome Click			Metronome Click			Metronome Click			Metronome Click		
22	A#-1	Metronome Bell			Metronome Bell			Metronome Bell			Metronome Bell			Metronome Bell		
23	B-1	Seq Click L			Seq Click L			Seq Click L			Seq Click L			Seq Click L		
24	C0	Seq Click H			Seq Click H			Seq Click H			Seq Click H			Seq Click H		
25	C#0	Brush Tap			Brush Tap			Brush Tap			Brush Tap			Brush Tap		
26	D0	Brush Swirl	●		Brush Swirl	●		Brush Swirl	●		Brush Swirl	●		Brush Swirl	●	
27	D#0	Brush Slap			Brush Slap			Brush Slap			Brush Slap			Brush Slap		
28	E0	Brush Tap Swirl	●		Brush Tap Swirl	●		Brush Tap Swirl	●		Brush Tap Swirl	●		Reverse Cymbal	●	
29	F0	Snare Roll	●		Snare Roll	●		Snare Roll	●		Snare Roll	●		Snare Roll	●	
30	F#0	Castanet			Castanet			Castanet			Castanet			Hi Q 2		
31	G0	Snare Soft			Snare Soft 2			Snare Soft			Snare Noisy			Snare Snappy Electro		
32	G#0	Sticks			Sticks			Sticks			Sticks			Sticks		
33	A0	Kick Soft			Kick Soft			Kick Soft			Kick Soft			Kick 3		
34	A#0	Open Rim Shot			Open Rim Shot H Short			Open Rim Shot			Open Rim Shot			Open Rim Shot		
35	B0	Kick Tight			Kick Tight			Kick Tight			Kick 2			Kick Gate		
36	C1	Kick			Kick Short			Kick			Kick Gate			Kick Gate Heavy		
37	C#1	Side Stick			Side Stick Light			Side Stick			Side Stick			Side Stick		
38	D1	Snare			Snare Short			Snare Snappy			Snare Rock			Snare Noisy 2		
39	D#1	Hand Clap			Hand Clap			Hand Clap			Hand Clap			Hand Clap		
40	E1	Snare Tight			Snare Tight H			Snare Tight Snappy			Snare Rock Tight			Snare Noisy 3		
41	F1	Floor Tom L			Floor Tom L			Tom Room 1			Tom Rock 1			Tom Electro 1		
42	F#1	Hi-Hat Closed		1	Hi-Hat Closed		1	Hi-Hat Closed		1	Hi-Hat Closed		1	Hi-Hat Closed		1
43	G1	Floor Tom H			Floor Tom H			Tom Room 2			Tom Rock 2			Tom Electro 2		
44	G#1	Hi-Hat Pedal		1	Hi-Hat Pedal		1	Hi-Hat Pedal		1	Hi-Hat Pedal		1	Hi-Hat Pedal		1
45	A1	Low Tom			Low Tom			Tom Room 3			Tom Rock 3			Tom Electro 3		
46	A#1	Hi-Hat Open		1	Hi-Hat Open		1	Hi-Hat Open		1	Hi-Hat Open		1	Hi-Hat Open		1
47	B1	Mid Tom L			Mid Tom L			Tom Room 4			Tom Rock 4			Tom Electro 4		
48	C2	Mid Tom H			Mid Tom H			Tom Room 5			Tom Rock 5			Tom Electro 5		
49	C#2	Crash Cymbal 1			Crash Cymbal 1			Crash Cymbal 1			Crash Cymbal 1			Crash Cymbal 1		
50	D2	High Tom			High Tom			Tom Room 6			Tom Rock 6			Tom Electro 6		
51	D#2	Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1		
52	E2	Chinese Cymbal			Chinese Cymbal			Chinese Cymbal			Chinese Cymbal			Chinese Cymbal		
53	F2	Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup		
54	F#2	Tambourine			Tambourine			Tambourine			Tambourine			Tambourine		
55	G2	Splash Cymbal			Splash Cymbal			Splash Cymbal			Splash Cymbal			Splash Cymbal		
56	G#2	Cowbell			Cowbell			Cowbell			Cowbell			Cowbell		
57	A2	Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2		
58	A#2	Vibraslap			Vibraslap			Vibraslap			Vibraslap			Vibraslap		
59	B2	Ride Cymbal 2			Ride Cymbal 2			Ride Cymbal 2			Ride Cymbal 2			Ride Cymbal 2		
60	C3	Bongo H			Bongo H			Bongo H			Bongo H			Bongo H		
61	C#3	Bongo L			Bongo L			Bongo L			Bongo L			Bongo L		
62	D3	Conga H Mute			Conga H Mute			Conga H Mute			Conga H Mute			Conga H Mute		
63	D#3	Conga H Open			Conga H Open			Conga H Open			Conga H Open			Conga H Open		
64	E3	Conga L			Conga L			Conga L			Conga L			Conga L		
65	F3	Timbale H			Timbale H			Timbale H			Timbale H			Timbale H		
66	F#3	Timbale L			Timbale L			Timbale L			Timbale L			Timbale L		
67	G3	Agogo H			Agogo H			Agogo H			Agogo H			Agogo H		
68	G#3	Agogo L			Agogo L			Agogo L			Agogo L			Agogo L		
69	A3	Cabasa			Cabasa			Cabasa			Cabasa			Cabasa		
70	A#3	Maracas			Maracas			Maracas			Maracas			Maracas		
71	B3	Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●	
72	C4	Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●	
73	C#4	Guiro Short			Guiro Short			Guiro Short			Guiro Short			Guiro Short		
74	D4	Guiro Long	●		Guiro Long	●		Guiro Long	●		Guiro Long	●		Guiro Long	●	
75	D#4	Claves			Claves			Claves			Claves			Claves		
76	E4	Wood Block H			Wood Block H			Wood Block H			Wood Block H			Wood Block H		
77	F4	Wood Block L			Wood Block L			Wood Block L			Wood Block L			Wood Block L		
78	F#4	Cuica Mute			Cuica Mute			Cuica Mute			Cuica Mute			Scratch H 2		
79	G4	Cuica Open			Cuica Open			Cuica Open			Cuica Open			Scratch L 2		
80	G#4	Triangle Mute		2	Triangle Mute		2	Triangle Mute		2	Triangle Mute		2	Triangle Mute		2
81	A4	Triangle Open		2	Triangle Open		2	Triangle Open		2	Triangle Open		2	Triangle Open		2
82	A#4	Shaker			Shaker			Shaker			Shaker			Shaker		
83	B4	Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells		
84	C5	Bell Tree			Bell Tree			Bell Tree			Bell Tree			Bell Tree		
85	C#5															
86	D5															
87	D#5															
88	E5															
89	F5															
90	F#5															
91	G5															

Same as Standard Kit 1  
Standard Kit 1と同じ

No Sound  
音は鳴りません

\*1 Key Off: Keys marked "●" stop sounding the instant they are released.  
\*1 Key Off時に「●」がついている楽器は、鍵盤を離したとき発音が止まります。

\*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

\*2 Alt Grp (Alternate Group)欄の番号はグループを表し、同じグループ番号の中で、1つの楽器を発音させると同じグループの中他の楽器の発音が止まります。

Kit Name		Analog Kit			Dance Kit			Jazz Kit			Brush Kit			Symphony Kit		
MSB-LSB-PC# (Org:1)		127-0-26			127-0-28			127-0-33			127-0-41			127-0-49		
Note#	MIDI Note	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	Surdo Mute		3	Kick Dance 1			Surdo Mute		3	Surdo Mute		3	Surdo Mute		3
14	D-1	Surdo Open		3	Kick Dance 2			Surdo Open		3	Surdo Open		3	Surdo Open		3
15	D#-1	Hi Q			Hi Q			Hi Q			Hi Q			Hi Q		
16	E-1	Whip Slap			Whip Slap	●		Whip Slap			Whip Slap			Whip Slap		
17	F-1	Scratch H		4	Scratch Dance 1	●		Scratch H		4	Scratch H		4	Scratch H		4
18	F#-1	Scratch L		4	Scratch Dance 2	●		Scratch L		4	Scratch L		4	Scratch L		4
19	G-1	Finger Snap			Finger Snap			Finger Snap			Finger Snap			Finger Snap		
20	G#-1	Click Noise			Click Noise			Click Noise			Click Noise			Click Noise		
21	A-1	Metronome Click			Dance Perc 1			Metronome Click			Metronome Click			Metronome Click		
22	A#-1	Metronome Bell			Reverse Dance 1			Metronome Bell			Metronome Bell			Metronome Bell		
23	B-1	Seq Click L			Dance Perc 2			Seq Click L			Seq Click L			Seq Click L		
24	C0	Seq Click H			Hi Q Dance 1			Seq Click H			Seq Click H			Seq Click H		
25	C#0	Brush Tap			Snare Analog 3			Brush Tap			Brush Tap			Brush Tap		
26	D0	Brush Swirl	●		Vinyl Noise	●		Brush Swirl	●		Brush Swirl	●		Brush Swirl	●	
27	D#0	Brush Slap			Snare Analog 4			Brush Slap			Brush Slap			Brush Slap		
28	E0	Reverse Cymbal	●		Reverse Cymbal	●		Brush Tap Swirl	●		Brush Tap Swirl	●		Brush Tap Swirl	●	
29	F0	Snare Roll	●		Reverse Dance 2	●		Snare Roll	●		Snare Roll	●		Snare Roll	●	
30	F#0	Hi Q 2			Hi Q 2			Castanet			Castanet			Castanet		
31	G0	Snare Noisy 4			Snare Techno			Snare Jazz H			Brush Slap 2			Snare Soft		
32	G#0	Sticks			Snare Dance 1			Sticks			Sticks			Sticks		
33	A0	Kick 3			Kick Techno Q			Kick Soft			Kick Soft			Kick Soft 2		
34	A#0	Open Rim Shot			Rim Gate			Open Rim Shot			Open Rim Shot			Open Rim Shot		
35	B0	Kick Analog Short			Kick Techno L			Kick Tight			Gran Cassa			Gran Cassa		
36	C1	Kick Analog			Kick Techno			Kick Jazz			Kick Jazz			Gran Cassa Mute		
37	C#1	Side Stick Analog			Side Stick Analog			Side Stick Light			Side Stick Light			Side Stick		
38	D1	Snare Analog			Snare Clap			Snare Jazz L			Brush Slap 3			Band Snare		
39	D#1	Hand Clap			Dance Clap			Hand Clap			Hand Clap			Hand Clap		
40	E1	Snare Analog 2			Snare Dry			Snare Jazz M			Brush Tap 2			Band Snare 2		
41	F1	Tom Analog 1			Tom Dance 1			Floor Tom L			Tom Brush 1			Floor Tom L		
42	F#1	Hi-Hat Closed Analog		1	Hi-Hat Closed 3		1	Hi-Hat Closed		1	Hi-Hat Closed		1	Hi-Hat Closed		1
43	G1	Tom Analog 2			Tom Dance 2			Floor Tom H			Tom Brush 2			Floor Tom H		
44	G#1	Hi-Hat Closed Analog 2		1	Hi-Hat Closed Analog 3		1	Hi-Hat Pedal		1	Hi-Hat Pedal		1	Hi-Hat Pedal		1
45	A1	Tom Analog 3			Tom Dance 3			Low Tom			Tom Brush 3			Low Tom		
46	A#1	Hi-Hat Open Analog		1	Hi-Hat Open 3		1	Hi-Hat Open		1	Hi-Hat Open		1	Hi-Hat Open		1
47	B1	Tom Analog 4			Tom Dance 4			Mid Tom L			Tom Brush 4			Mid Tom L		
48	C2	Tom Analog 5			Tom Dance 5			Mid Tom H			Tom Brush 5			Mid Tom H		
49	C#2	Crash Analog			Crash Analog			Crash Cymbal 1			Crash Cymbal 1			Hand Cymbal		
50	D2	Tom Analog 6			Tom Dance 6			High Tom			Tom Brush 6			High Tom		
51	D#2	Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1			Hand Cymbal Short		
52	E2	Chinese Cymbal			Chinese Cymbal			Chinese Cymbal			Chinese Cymbal			Chinese Cymbal		
53	F2	Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup		
54	F#2	Tambourine			Tambourine Analog			Tambourine			Tambourine			Tambourine		
55	G2	Splash Cymbal			Splash Cymbal			Splash Cymbal			Splash Cymbal			Splash Cymbal		
56	G#2	Cowbell Analog			Cowbell Dance			Cowbell			Cowbell			Cowbell		
57	A2	Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2			Hand Cymbal 2		
58	A#2	Vibraslap			Vibraslap Analog			Vibraslap			Vibraslap			Vibraslap		
59	B2	Ride Cymbal 2			Ride Analog			Ride Cymbal 2			Ride Cymbal 2			Hand Cymbal Short 2		
60	C3	Bongo H			Bongo Analog H			Bongo H			Bongo H			Bongo H		
61	C#3	Bongo L			Bongo Analog L			Bongo L			Bongo L			Bongo L		
62	D3	Conga Analog H			Conga Analog H			Conga H Mute			Conga H Mute			Conga H Mute		
63	D#3	Conga Analog M			Conga Analog M			Conga H Open			Conga H Open			Conga H Open		
64	E3	Conga Analog L			Conga Analog L			Conga L			Conga L			Conga L		
65	F3	Timbale H			Timbale H			Timbale H			Timbale H			Timbale H		
66	F#3	Timbale L			Timbale L			Timbale L			Timbale L			Timbale L		
67	G3	Agogo H			Agogo H			Agogo H			Agogo H			Agogo H		
68	G#3	Agogo L			Agogo L			Agogo L			Agogo L			Agogo L		
69	A3	Cabasa			Cabasa			Cabasa			Cabasa			Cabasa		
70	A#3	Maracas 2			Maracas 2			Maracas			Maracas			Maracas		
71	B3	Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●	
72	C4	Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●	
73	C#4	Guiro Short			Guiro Short			Guiro Short			Guiro Short			Guiro Short		
74	D4	Guiro Long	●		Guiro Long	●		Guiro Long	●		Guiro Long	●		Guiro Long	●	
75	D#4	Claves 2			Claves 2			Claves			Claves			Claves		
76	E4	Wood Block H			Dance Perc 3			Wood Block H			Wood Block H			Wood Block H		
77	F4	Wood Block L			Dance Perc 4	●		Wood Block L			Wood Block L			Wood Block L		
78	F#4	Scratch H 2			Dance Breath 1			Cuica Mute			Cuica Mute			Cuica Mute		
79	G4	Scratch L 2			Dance Breath 2	●		Cuica Open			Cuica Open			Cuica Open		
80	G#4	Triangle Mute	2		Triangle Mute	2		Triangle Mute	2		Triangle Mute	2		Triangle Mute	2	
81	A4	Triangle Open	2		Triangle Open	2		Triangle Open	2		Triangle Open	2		Triangle Open	2	
82	A#4	Shaker			Shaker			Shaker			Shaker			Shaker		
83	B4	Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells		
84	C5	Bell Tree			Bell Tree			Bell Tree			Bell Tree			Bell Tree		
85	C#5															
86	D5															
87	D#5															
88	E5															
89	F5															
90	F#5															
91	G5															

Kit Name		Power Kit		
MSB-LSB-PC# (Org:1)		127-0-88		
Note#	MIDI Note	FullName	Key Off	Alt Grp
13	C#-1	Surdo Mute		3
14	D-1	Surdo Open		3
15	D#-1	Hi Q		
16	E-1	Whip Slap		
17	F-1	Scratch H		4
18	F#-1	Scratch L		4
19	G-1	Finger Snap		
20	G#-1	Click Noise		
21	A-1	Metronome Click		
22	A#-1	Metronome Bell		
23	B-1	Seq Click L		
24	C0	Seq Click H		
25	C#0	Brush Tap		
26	D0	Brush Swirl	●	
27	D#0	Brush Slap		
28	E0	Brush Tap Swirl	●	
29	F0	Snare Roll	●	
30	F#0	Castanet		
31	G0	Snare Soft Power 1		
32	G#0	Sticks		
33	A0	Kick Ambient+		
34	A#0	Open Rim Power 1		
35	B0	Kick Power Open		
36	C1	Kick Power Mute		
37	C#1	Side Stick Power		
38	D1	Snare Power 1		
39	D#1	Hand Clap Power		
40	E1	Snare Rough		
41	F1	Tom Power 1		
42	F#1	Hi-Hat Closed Power		1
43	G1	Tom Power 2		
44	G#1	Hi-Hat Pedal Power		1
45	A1	Tom Power 3		
46	A#1	Hi-Hat Open Power		1
47	B1	Tom Power 4		
48	C2	Tom Power 5		
49	C#2	Crash Cymbal Acoustic 1		
50	D2	Tom Power 6		
51	D#2	Ride Cymbal Acoustic 1		
52	E2	China Cymbal Acoustic		
53	F2	Ride Cymbal Cup Acoustic		
54	F#2	Tambourine		
55	G2	Splash Cymbal Acoustic		
56	G#2	Cowbell		
57	A2	Crash Cymbal Acoustic 2		
58	A#2	Vibraslap		
59	B2	Ride Cymbal Acoustic 2		
60	C3	Bongo H		
61	C#3	Bongo L		
62	D3	Conga H Mute		
63	D#3	Conga H Open		
64	E3	Conga L		
65	F3	Timbale H		
66	F#3	Timbale L		
67	G3	Agogo H		
68	G#3	Agogo L		
69	A3	Cabasa		
70	A#3	Maracas		
71	B3	Samba Whistle H	●	
72	C4	Samba Whistle L	●	
73	C#4	Guiro Short		
74	D4	Guiro Long	●	
75	D#4	Claves		
76	E4	Wood Block H		
77	F4	Wood Block L		
78	F#4	Cuica Mute		
79	G4	Cuica Open		
80	G#4	Triangle Mute		2
81	A4	Triangle Open		2
82	A#4	Shaker		
83	B4	Jingle Bells		
84	C5	Wind Chime		
85	C#5			
86	D5			
87	D#5			
88	E5			
89	F5			
90	F#5			
91	G5			

Kit Name		SFX Kit 1			SFX Kit 2			Pop Latin Kit		
MSB-LSB-PC# (Org:1)		126-0-1			126-0-2			126-0-44		
Note#	MIDI Note	FullName	Key Off (*1)	Alt Grp (*2)	FullName	Key Off	Alt Grp	FullName	Key Off	Alt Grp
13	C#-1							Cajon Low		
14	D-1							Cajon Slap		
15	D#-1							Cajon Tip		
16	E-1							Claves High		
17	F-1							Claves Low		
18	F#-1							Hand Clap		
19	G-1									
20	G#-1							Finger Snap		
21	A-1							Castanet		
22	A#-1							Conga H Tip		
23	B-1							Conga H Heel		
24	C0							Conga H Open		
25	C#0							Conga H Mute		
26	D0							Conga H Slap Open		
27	D#0							Conga H Slap		
28	E0							Conga H Slap Mute		
29	F0							Conga L Tip		
30	F#0							Conga L Heel		
31	G0							Conga L Open		
32	G#0							Conga L Mute		
33	A0							Conga L Slap Open		
34	A#0							Conga L Slap		
35	B0							Conga L Slide	●	
36	C1	Cutting Noise 1	●		Phone Call	●		Bongo H Open One Finger		
37	C#1	Cutting Noise 2	●		Door Squeak	●		Bongo H Open Three Finger		
38	D1				Door Slam	●		Bongo H Rim		
39	D#1	String Slap	●		Scratch Cut	●		Bongo H Tip		
40	E1				Scratch Split	●		Bongo H Heel		
41	F1				Wind Chime	●		Bongo H Slap		
42	F#1				Telephone Ring	●		Bongo L Open One Finger		
43	G1							Bongo L Open Three Finger		
44	G#1							Bongo L Rim		
45	A1							Bongo L Tip		
46	A#1							Bongo L Heel		
47	B1							Bongo L Slap		
48	C2							Timbale L		
49	C#2									
50	D2									
51	D#2									
52	E2	Flute Key Click	●		Car Engine Ignition	●				
53	F2				Car Tires Squeak	●		Paila L		
54	F#2				Car Passing	●		Timbale H		
55	G2				Car Crash	●				
56	G#2				Siren	●				
57	A2				Train	●				
58	A#2				Jet Plane	●				
59	B2				Starship	●		Paila H		
60	C3				Burst	●		Cowbell Top		
61	C#3				Roller Coaster	●		Cowbell 1		
62	D3				Submarine	●		Cowbell 2		
63	D#3							Cowbell 3		
64	E3							Guiro Short		
65	F3							Guiro Long	●	
66	F#3							Metal Guiro Short		
67	G3							Metal Guiro Long	●	
68	G#3	Shower	●		Laugh	●		Tambourine		
69	A3	Thunder	●		Scream	●		Tambourim Open		
70	A#3	Wind	●		Punch	●		Tambourim Mute		
71	B3	Stream	●		Heart Beat	●		Tambourim Tip		
72	C4	Bubble	●		Foot Steps	●		Maracas		
73	C#4	Feed	●					Shaker		
74	D4							Cabasa		
75	D#4							Cuica Mute		
76	E4							Cuica Open		
77	F4							Cowbell High 1		
78	F#4							Cowbell High 2		
79	G4							Shekere		
80	G#4							Shekere Tone		
81	A4							Triangle Mute		1
82	A#4							Triangle Open		1
83	B4									
84	C5	Dog	●		Machine Gun	●		Wind Chime		
85	C#5	Horse	●		Laser Gun	●				
86	D5	Bird Tweet	●		Explosion	●				
87	D#5				Firework	●				
88	E5									
89	F5									
90	F#5	Ghost	●							
91	G5	Maou	●							