



# THR Editor Install Guide

## Special Notices

- The software and this Installation Guide are the exclusive copyrights of Yamaha Corporation.
- Copying of the software or reproduction of this Installation Guide in whole or in part by any means is expressly forbidden without the written consent of the manufacturer.
- Yamaha makes no representations or warranties with regard to the use of the software and documentation and cannot be held responsible for the results of the use of this Installation Guide and the software.
- For information about the latest information of THR Editor, check the web site below.  
<http://download.yamaha.com/>
- The screen displays as illustrated in this Installation Guide are for instructional purposes, and may appear somewhat different from the screens which appear on your computer.
- Copying of the commercially available musical data including but not limited to MIDI data and/or audio data is strictly prohibited except for your personal use.
- Click on the [blue-colored](#) text to jump to the related item in this manual.
- Windows is a registered trademark of Microsoft® Corporation in the United States and other countries.
- Apple, Mac and Macintosh are trademarks of Apple Inc., registered in the U.S. and other countries.
- Steinberg is a registered trademark of Steinberg Media Technologies GmbH.
- The company names and product names in this Installation Guide are the trademarks or registered trademarks of their respective companies.
- Future upgrades of application and system software (e.g., firmware of the products) and any changes in specifications and functions will be announced at the following website.

[http:// download.yamaha.com/](http://download.yamaha.com/)

This Installation Guide assumes that you are already familiar with basic Windows/Macintosh operations. If you are not, please refer to the owner's manual which came with your Windows/Mac OS software before using the THR Editor.

For information on software and hardware requirements and the interconnection of devices that are required to use the THR Editor, please refer to the Owner's Manual that came with your THR guitar amp.

The screen illustrations in this manual are mainly taken from Windows (with the THR10 connected). Differences that exist in the Macintosh version are duly shown and explained.

## What is the THR Editor?

The THR Editor is a software application that lets you freely edit settings and create patch files on a computer screen for Yamaha's THR Guitar Amplifier. In addition to the main controls on the THR guitar amp, it provides settings for the compressor, noise gate, and speaker cabinet for more precise sound shaping. Listening to the actual sound change as you turn the knobs on the screen lets you create sound intuitively. You can save the patch files you create on your computer and create libraries of sounds.


## Installing the THR Editor

Before installing the THR Editor, please install the Yamaha Steinberg USB Driver on your computer and choose the model name (THR10 etc.) of the connected THR guitar amp as the audio output for your computer.

\* Please refer to the THR guitar amp Owner's Manual for more information on installing the Yamaha Steinberg USB Driver and setting the audio output.

### ■ Install the THR Editor

1. Access the Yamaha download site at <http://download.yamaha.com/> and download the THR Editor that matches your computer's requirements.
2. Run the downloaded file and follow the onscreen instructions to install the THR Editor.
3. Connect the THR guitar amp to your computer using the supplied USB cable, and then turn the THR guitar amp power ON.





4. Start the THR Editor application on your computer.  
The display shown below appears when the THR Editor starts up.





5. Confirm that the THR editor properly recognizes the THR guitar amp.

**For Windows:** Open the Preferences window [Edit]



**For Macintosh:** Open the Preferences window [THR Editor]



Make sure that the name of the THR guitar amp model that is connected appears in both the “DATA IN” and “DATA OUT” fields.

- \* If the name of a different device appears in the “DATA IN”, “DATA OUT” fields, select the name of the connected THR guitar amp.
- \* If the name of the connected THR guitar amp is not shown in the display, make sure that the USB cable is properly connected.

6. After confirmation is complete, click the [OK] button.

The controls shown on the display reflect the current condition of controls on the connected THR guitar amp.

7. “CONNECTED” appears in the lower right corner of the display, and the controls shown on the display reflect the current condition of controls on the connected THR guitar amp.

- \* If “DISCONNECTED” appears in the lower right corner of the display, the THR guitar amp connection is not recognized. Make sure that the USB cable is properly connected.

**This completes installation of the THR Editor.**

**Please refer to the THR Editor manual (PDF) for information on THR Editor settings and operation.**